

INSTRUCTION SHEET



CPDB 125/4, CPDB 125/9, CPDB 150/4, CPDB 150/6
 (2112101254, 2112101259, 2112101504, 2112101506)



SEP One pole distribution block, 125A / 4,5kA

CPDB 125/4
2112101254



CPDB 125/9
2112101259



SEP One pole distribution block, 150A / 10kA

CPDB 150/4
2112101504

CPDB 150/6
2112101506



					CPDB125/4 2112101254	CPDB125/9 2112101259	CPDB150/4 2112101504	CPDB150/6 2112101506
	6 Nm	10mm ² - 35mm ²	10mm ² - 35mm ²	HEX 8	1x	1x		
	10 Nm	16mm ² - 50mm ²	16mm ² - 50mm ²	HEX 8			1x	1x
	0,5 - 1,2 Nm	1mm ² - 4mm ²	0,5mm ² - 1mm ²	M3		9x		
	1,2 - 1,8 Nm	2,5mm ² - 10mm ²	1,5mm ² - 6mm ²	M4	4x			6x
	1,5 - 2 Nm	4mm ² - 16mm ²	1,5mm ² - 6mm ²	M4			4x	

Note:

Unused openings should be tighten to a torque of 0,5 - 1 Nm

WARNING:

All products shall be installed and used as indicated by SEP Europe in the instruction sheets and training materials. Products must never be used for a purpose other than which they were designed for or in a manner that exceeds the specified ratings. Installations must be carried out in accordance with the applicable national rules for electrical installations.